




PROSTOR 500 SPARE PARTS



1	5001001 - z 5000791 - z 5000787 - z 5000792 - z 5000788 - z	BACK PROFILE 4.0M BACK PROFILE 4.5M BACK PROFILE 5.0M BACK PROFILE 5.5M BACK PROFILE 7.0M
2	5001000 - z 5000797 - z 5000918 - z 5000798 - z 5000811 - z	LEADRAIL PROFILE 4.0M LIGHT LEADRAIL PROFILE 4.5M LEADRAIL PROFILE 5.0M LEADRAIL PROFILE 5.5M LEADRAIL PROFILE 7.0M LIGHT
3	0300089 - 260 0300089 - 300 0300089 - 350 0300089 - 400 0300085 - 450 0300085 - 500 0300085 - 550 0100190	ROLLER TUBE MANUAL DIA 48 2.6M ROLLER TUBE MANUAL DIA 48 3.0M ROLLER TUBE MANUAL DIA 48 3.5M ROLLER TUBE MANUAL DIA 48 4.0M ROLLER TUBE MANUAL DIA 58 4.5M ROLLER TUBE MANUAL DIA 58 5.0M ROLLER TUBE MANUAL DIA 58 5.5M ROLLER TUBE MOTOR 5.5M
4	5400143 - xxx - y 5400144 - xxx - y 5400145 - xxx - y 5400146 - xxx - y	JAMAICA ARUBA GREY WAVES BLUE WAVES
5	5400001 5400007 5400009 5400002	SPRING ARM 1.00M LEFT SPRING ARM 2.00M LEFT SPRING ARM 2.50M LEFT SPRING ARM 1.00M RIGHT
6	5400008 5400010	SPRING ARM 2.00M RIGHT SPRING ARM 2.50M RIGHT
7	5400021 - z	ENDCAP BACKPROFILE MANUAL LEFT
8	5400022 - z	ENDCAP BACKPROFILE MANUAL RIGHT MANUAL 4.00M OR LESS / MOTOR
9	5400023 - z	ENDCAP LEADRAIL LEFT
10	5400024 - z	ENDCAP LEADRAIL RIGHT
11	5400015 5400017 5400019	SUPPORT LEG 2.60M SUPPORT LEG 3.00M SUPPORT LEG 3.50M OR MORE

12	5400040	LOWER STOP + CON. LEADRAIL LEFT
13	5400041	LOWER STOP + CON. LEADRAIL RIGHT
14	5400011	ARMSUPPORT LEFT 3.50M OR LESS
15	5400046 5400012 5400047	ARMSUPPORT LEFT 4.00M OR MORE ARMSUPPORT RIGHT 3.50M OR LESS ARMSUPPORT RIGHT 4.00M OR MORE
16	0900085 0900092 0900084 0900093	TUBE BUSH D58 WITH SQUARE AXLE TUBE BUSH D48 WITH SQUARE AXLE TUBE BUSH D58 WITHOUT SQUARE AXLE TUBE BUSH D48 WITHOUT SQUARE AXLE
17	5400124	ADJUSTABLE CRANK RV
18	5000921 - z	ENDCAP BACKPROFILE LEFT
19	0900086	GEAR
20	0500164	BEARING ROLLERTUBE
21	0200156	COUPLING FUNNEL
22	5000922 - z	ENDCAP BACKPROFILE RIGHT MANUAL 4.00M OR LESS / MOTOR
23	0300079	END COURSE PLATE
24	0500208	LOGOPLATE LB
25	0500211	COVER LOWER STOP LEFT
26	0500212	COVER LOWER STOP RIGHT
27	0500182	LOGO PROSTOR
28	5400129	MOUNTING BRACKET
29	0900028	CRANK HOLDER 25 MM
30	0500174	TENSION RAFTER LEADRAIL PIECE
31	5000917	GLIDING ANGLE PROFILE 6.0M
32	5400025	ROLLER TUBE SUPPORT
33	5100378	TUBES TENSION RAFTER
34	5400054	TENSION RAFTER SHOE
35	5000999 - z	ENDCAP BACKPROFILE LEFT - FOR MOTOR
36	0400230	MOTORPLATE
37	1000241	TUBULAR MOTOR
38	0200138 & 140	SUPPORT LEG UPPER STOP & ROTATION
39		

xxx : LENGTH
y : CONTROL
- 0 MANUAL
- 1 MOTOR

z : Color
- 0 WHITE
- 1 ANO